

Device:	Rev:	Device ID:
DSPIC30F1010		0x4040000
DSPIC30F1010	msp2 a0	0x3401000
DSPIC30F2005		0x3c2000
DSPIC30F2005	mm3 a0	0x3c2000
DSPIC30F2010		0x400000
DSPIC30F2010	mm3 a0	0x401000
dsPIC30F2010A		0x00400000
dsPIC30F2010A	mm3 a0	0x00401000
DSPIC30F2010E		0x400000
DSPIC30F2010E	mm3 a0	0x401000
DSPIC30F2011		0x2400000
DSPIC30F2011	ms2 a0	0xc01000
DSPIC30F2011	ms2 a1	0xc01001
DSPIC30F2011	ms1 a0	0x2401000
DSPIC30F2011E		0xc00000
DSPIC30F2011E	ms2 a0	0xc01000
DSPIC30F2011E	ms2 a1	0xc01001
DSPIC30F2011E	ms1 a0	0x2401000
DSPIC30F2012		0x2410000
DSPIC30F2012	ms2 a0	0xc21000
DSPIC30F2012	ms1 a0	0x2411000
DSPIC30F2012E		0xc20000
DSPIC30F2012E	ms2 a0	0xc21000
DSPIC30F2012E	ms1 a0	0x2411000
DSPIC30F2020		0x4000000
DSPIC30F2020	msp2 a0	0x3401000
dsPIC30F2020PS		0x00d00000
DSPIC30F2021		0x4010000
DSPIC30F2022		0x4020000
DSPIC30F2022	msp2 a0	0x3421000
dsPIC30F2022PS		0x00b20000
DSPIC30F2023		0x4030000
DSPIC30F2023	msp2 a0	0x3431000
dsPIC30F2023PS		0x00b30000
DSPIC30F3010		0x1c00000
DSPIC30F3010	mm2 a0	0x1c01000
DSPIC30F3010E		0x1c00000
DSPIC30F3010E	mm2 a0	0x1c01000
DSPIC30F3011		0x1c10000
DSPIC30F3011	mm2 a0	0x1c11000
DSPIC30F3011E		0x1c10000
DSPIC30F3011E	mm2 a0	0x1c11000
DSPIC30F3012		0xc10000
DSPIC30F3012	pam a2	0xa0000
DSPIC30F3012	ms2 a0	0xc11000
DSPIC30F3012E		0xc10000
DSPIC30F3012E	pam a2	0xa0000
DSPIC30F3012E	ms2 a0	0xc11000
DSPIC30F3013		0xc30000
DSPIC30F3013	pam a2	0xc0000
DSPIC30F3013	ms2 a0	0xc31000
DSPIC30F3013E		0xc30000
DSPIC30F3013E	pam a2	0xc0000
DSPIC30F3013E	ms2 a0	0xc31000
DSPIC30F3014		0x1600000

Device:	Rev:	Device ID:
DSPIC30F3014	mg1 a0	0x1601000
DSPIC30F3014E		0x1600000
DSPIC30F3014E	mg1 a0	0x1601000
DSPIC30F4011		0x1010000
DSPIC30F4011	pam a2	0x50000
DSPIC30F4011	mm1 a0	0x1011000
DSPIC30F4011	mm1 a1	0x1011001
DSPIC30F4011E		0x1010000
DSPIC30F4011E	pam a2	0x50000
DSPIC30F4011E	mm1 a0	0x1011000
DSPIC30F4011E	mm1 a1	0x1011001
DSPIC30F4012		0x1000000
DSPIC30F4012	pam a2	0x30000
DSPIC30F4012	mm1 a0	0x1001000
DSPIC30F4012E		0x1000000
DSPIC30F4012E	pam a2	0x30000
DSPIC30F4012E	mm1 a0	0x1001000
DSPIC30F4013		0x1410000
DSPIC30F4013	pam a2	0xe0000
DSPIC30F4013	mg1 a0	0x1411000
DSPIC30F4013	mg1 a1	0x1411001
DSPIC30F4013E		0x1410000
DSPIC30F4013E	pam a2	0xe0000
DSPIC30F4013E	mg1 a0	0x1411000
DSPIC30F5011		0x800000
DSPIC30F5011	mg3 a1	0x801000
DSPIC30F5011E		0x800000
DSPIC30F5011E	mg3 a1	0x801000
DSPIC30F5013		0x810000
DSPIC30F5013	mg3 a1	0x811000
DSPIC30F5013E		0x810000
DSPIC30F5013E	mg3 a1	0x811000
DSPIC30F5015		0x2001000
DSPIC30F5015E		0x60000
DSPIC30F5016		0x2011000
DSPIC30F6010		0x1880000
DSPIC30F6010	mss1 a1,a2	0x80000
DSPIC30F6010	mss1.b a0,a2,a3	0x81040
DSPIC30F6010	mss1.b b1	0x1881040
DSPIC30F6010	mss1.b b2	0x1881042
DSPIC30F6010A		0x2810000
DSPIC30F6010A	mss1 a1,a2	0x80000
DSPIC30F6010A	mss1.b a0,a2,a3	0x81040
DSPIC30F6010A	mss1.b b1	0x1881040
DSPIC30F6010A	mss1.b b2	0x1881042
DSPIC30F6010A	mm5 a0	0x2811000
DSPIC30F6011		0x1920000
DSPIC30F6011	mss1 a1,a2	0x120000
DSPIC30F6011	mss1.b a0,a2,a3	0x121040
DSPIC30F6011	mss1.b b1	0x1921040
DSPIC30F6011	mss1.b b2	0x1921042
DSPIC30F6011A		0x2c00000
DSPIC30F6011A	mss1 a1,a2	0x120000
DSPIC30F6011A	mss1.b a0,a2,a3	0x121040
DSPIC30F6011A	mss1.b b1	0x1921040

Device:	Rev:	Device ID:
DSPIC30F6011A	mss1.b b2	0x1921042
DSPIC30F6011A	mg6 a0	0x2c01042
DSPIC30F6012		0x1930000
DSPIC30F6012	mss1 a1,a2	0x130000
DSPIC30F6012	mss1.b a0,a2,a3	0x131040
DSPIC30F6012	mss1.b b1	0x1931040
DSPIC30F6012	mss1.b b2	0x1931042
DSPIC30F6012A		0x2c20000
DSPIC30F6012A	mss1 a1,a2	0x130000
DSPIC30F6012A	mss1.b a0,a2,a3	0x131040
DSPIC30F6012A	mss1.b b1	0x1931040
DSPIC30F6012A	mss1.b b2	0x1931042
DSPIC30F6012A	mg6 a0	0x2c21000
DSPIC30F6013		0x1970000
DSPIC30F6013	mss1 a1,a2	0x170000
DSPIC30F6013	mss1.b a0,a2,a3	0x171040
DSPIC30F6013	mss1.b b1	0x1971040
DSPIC30F6013	mss1.b b2	0x1971042
DSPIC30F6013A		0x2c10000
DSPIC30F6013A	mss1 a1,a2	0x170000
DSPIC30F6013A	mss1.b a0,a2,a3	0x171040
DSPIC30F6013A	mss1.b b1	0x1971040
DSPIC30F6013A	mss1.b b2	0x1971042
DSPIC30F6013A	mg6 a0	0x2c11000
DSPIC30F6014		0x1980000
DSPIC30F6014	mss1 a1,a2	0x180000
DSPIC30F6014	mss1.b a0,a2,a3	0x181040
DSPIC30F6014	mss1.b b1	0x1981040
DSPIC30F6014	mss1.b b2	0x1981042
DSPIC30F6014A		0x2c30000
DSPIC30F6014A	mss1 a1,a2	0x180000
DSPIC30F6014A	mss1.b a0,a2,a3	0x181040
DSPIC30F6014A	mss1.b b1	0x1981040
DSPIC30F6014A	mss1.b b2	0x1981042
DSPIC30F6014A	mg6 a0	0x2c31000
DSPIC30F6015		0x2800000
DSPIC30F6015	mss1 a1,a2	0x80000
DSPIC30F6015	mss1.b a0,a2,a3	0x81040
DSPIC30F6015	mss1.b b1	0x1881040
DSPIC30F6015	mss1.b b2	0x1881042
DSPIC30F6015	mm5 a0	0x2801000
dsPIC30SUPER		vid (region=0xFF0000-0xF
DSPIC33EP256MU806		0x18614000
DSPIC33EP256MU810		0x18624000
DSPIC33EP256MU814		0x18634000
DSPIC33EP512MU810		0x18724000
DSPIC33EP512MU814		0x18734000
DSPIC33FJ06GS101		0xc003000
DSPIC33FJ06GS102		0xc013000
DSPIC33FJ06GS202		0xc023000
DSPIC33FJ128GP202		0x6250000
DSPIC33FJ128GP204		0x6270000
DSPIC33FJ128GP206		0xd90000
DSPIC33FJ128GP206A		0xd93000
dsPIC33FJ128GP302		0x00250000

Device:	Rev:	Device ID:
dsPic33FJ128GP304		0x00260000
DSPIC33FJ128GP306		0xe50000
DSPIC33FJ128GP306A		0xe53000
DSPIC33FJ128GP310		0xe70000
DSPIC33FJ128GP310A		0xe73000
DSPIC33FJ128GP706		0xed0000
DSPIC33FJ128GP706A		0xed3000
DSPIC33FJ128GP708		0xee0000
DSPIC33FJ128GP708A		0xee3000
DSPIC33FJ128GP710		0xef0000
DSPIC33FJ128GP710A		0xef3000
DSPIC33FJ128GP802		0x62d0000
DSPIC33FJ128GP804		0x62f0000
DSPIC33FJ128MC202		0x6210000
DSPIC33FJ128MC204		0x6230000
dsPic33FJ128MC502		0x00290000
dsPic33FJ128MC504		0x002A0000
DSPIC33FJ128MC506		0xa10000
DSPIC33FJ128MC506A		0xa13000
DSPIC33FJ128MC510		0xa30000
DSPIC33FJ128MC510A		0xa33000
DSPIC33FJ128MC706		0xa90000
DSPIC33FJ128MC706A		0xa93000
DSPIC33FJ128MC708		0xae0000
DSPIC33FJ128MC708A		0xae3000
DSPIC33FJ128MC710		0xaf0000
DSPIC33FJ128MC710A		0xaf3000
DSPIC33FJ128MC802		0x6290000
DSPIC33FJ128MC804		0x62b0000
DSPIC33FJ12GP201		0x8020000
DSPIC33FJ12GP202		0x8030000
DSPIC33FJ12MC201		0x8000000
DSPIC33FJ12MC202		0x8010000
DSPIC33FJ16GP101		0x2003000
DSPIC33FJ16GP102		0x2013000
dsPic33FJ16GP302		0x0F050000
DSPIC33FJ16GP304		0xf070000
DSPIC33FJ16GS402		0xc043000
DSPIC33FJ16GS404		0xc063000
DSPIC33FJ16GS502		0xc033000
DSPIC33FJ16GS504		0xc053000
DSPIC33FJ16MC101		0x2023000
DSPIC33FJ16MC102		0x2033000
dsPic33FJ16MC302		0x0F010000
DSPIC33FJ16MC304		0xf030000
DSPIC33FJ256GP506		0xf50000
DSPIC33FJ256GP506A		0x7f50000
DSPIC33FJ256GP510		0xf70000
DSPIC33FJ256GP510A		0x7f70000
DSPIC33FJ256GP710		0xff0000
DSPIC33FJ256GP710A		0x7ff0000
DSPIC33FJ256MC510		0xb70000
DSPIC33FJ256MC510A		0x7b70000
DSPIC33FJ256MC710		0xbf0000
DSPIC33FJ256MC710A		0x7bf0000

Device:	Rev:	Device ID:
DSPIC33FJ32GP202		0xf0d0000
DSPIC33FJ32GP204		0xf0f0000
DSPIC33FJ32GP302		0x6050000
DSPIC33FJ32GP304		0x6070000
DSPIC33FJ32GS406		0x40003000
DSPIC33FJ32GS606		0x40023000
DSPIC33FJ32GS608		0x40043000
DSPIC33FJ32GS610		0x40063000
DSPIC33FJ32MC202		0xf090000
DSPIC33FJ32MC204		0xf0b0000
DSPIC33FJ32MC302		0x6010000
DSPIC33FJ32MC304		0x6030000
DSPIC33FJ64GP202		0x6150000
DSPIC33FJ64GP204		0x6170000
DSPIC33FJ64GP206		0xc10000
DSPIC33FJ64GP206A		0xc13000
dsPic33FJ64GP302		0x00150000
dsPic33FJ64GP304		0x00160000
DSPIC33FJ64GP306		0xcd0000
DSPIC33FJ64GP306A		0xcd3000
DSPIC33FJ64GP310		0xcf0000
DSPIC33FJ64GP310A		0xcf3000
DSPIC33FJ64GP706		0xd50000
DSPIC33FJ64GP706A		0xd53000
DSPIC33FJ64GP708		0xd60000
DSPIC33FJ64GP708A		0xd63000
DSPIC33FJ64GP710		0xd70000
DSPIC33FJ64GP710A		0xd73000
DSPIC33FJ64GP802		0x61d0000
DSPIC33FJ64GP804		0x61f0000
DSPIC33FJ64GS406		0x40013000
DSPIC33FJ64GS606		0x40033000
DSPIC33FJ64GS608		0x40053000
DSPIC33FJ64GS610		0x40073000
DSPIC33FJ64MC202		0x6110000
DSPIC33FJ64MC204		0x6130000
dsPic33FJ64MC502		0x00190000
dsPic33FJ64MC504		0x001A0000
DSPIC33FJ64MC506		0x890000
DSPIC33FJ64MC506A		0x893000
DSPIC33FJ64MC508		0x8a0000
DSPIC33FJ64MC508A		0x8a3000
DSPIC33FJ64MC510		0x8b0000
DSPIC33FJ64MC510A		0x8b3000
DSPIC33FJ64MC706		0x910000
DSPIC33FJ64MC706A		0x913000
DSPIC33FJ64MC710		0x970000
DSPIC33FJ64MC710A		0x973000
DSPIC33FJ64MC802		0x6190000
DSPIC33FJ64MC804		0x61b0000
PIC12F1822		0x2700
PIC12F1822	a0	0x2700
PIC12F1840		0x1b80
PIC12F1840	a0	0x1B80
PIC12F609		0x2240

Device:	Rev:	Device ID:
PIC12F615		0x2180
PIC12F617		0x1360
PIC12F629		0xf80
PIC12F635		0xfa0
PIC12F675		0xfc0
PIC12F683		0x460
PIC12F752		0x1500
PIC12HV609		0x2280
PIC12HV615		0x21a0
PIC12HV752		0x1520
PIC12LF1822		0x2800
PIC12LF1822	a0	0x2800
PIC12LF1840		0x1bc0
PIC12LF1840	a0	0x1BC0
PIC16C745		0xb60
PIC16C765		0xb80
PIC16C925		0x140
PIC16C925	a2	0x141
PIC16C925	b1	0x143
PIC16C925	b2	0x144
PIC16C926		0x100
PIC16C926	a2	0x101
PIC16C926	b1	0x103
PIC16C926	b2	0x104
PIC16CR73		0xc80
PIC16CR73	Rev A	0xc80
PIC16CR74		0xcc0
PIC16CR74	Rev A	0xcc0
PIC16CR76		0xc00
PIC16CR76	Rev A	0xc00
PIC16CR77		0xc40
PIC16CR77	Rev A	0xc40
PIC16CR926		0x2100
PIC16F1516		0x1680
PIC16F1516	a0	0x16E0
PIC16F1517		0x16a0
PIC16F1517	a0	0x16E0
PIC16F1518		0x16c0
PIC16F1518	a0	0x16E0
PIC16F1519		0x16e0
PIC16F1519	a0	0x16E0
PIC16F1526		0x1580
PIC16F1526	a0	0x1580
PIC16F1527		0x15a0
PIC16F1527	a0	0x15A0
PIC16F1782		0x2a00
PIC16F1782	a0	0x2A00
PIC16F1783		0x2a20
PIC16F1783	a0	0x2A20
PIC16F1823		0x2720
PIC16F1823	a0	0x2720
PIC16F1824		0x2740
PIC16F1824	a0	0x2740
PIC16F1825		0x2760
PIC16F1825	a0	0x2760

Device:	Rev:	Device ID:
PIC16F1826		0x2780
PIC16F1826	a0	0x2780
PIC16F1827		0x27a0
PIC16F1827	a0	0x27A0
PIC16F1828		0x27c0
PIC16F1828	a0	0x27C0
PIC16F1829		0x27e0
PIC16F1829	a0	0x27E0
PIC16F1847		0x1480
PIC16F1847	a0	0x1480
PIC16F1933		0x2300
PIC16F1933	a0	0x2300
PIC16F1934		0x2340
PIC16F1934	a0	0x2340
PIC16F1936		0x2360
PIC16F1936	a0	0x2360
PIC16F1937		0x2380
PIC16F1937	a0	0x2380
PIC16F1938		0x23a0
PIC16F1938	a0	0x23A0
PIC16F1939		0x23c0
PIC16F1939	a0	0x24C0
PIC16F1946		0x2500
PIC16F1946	a0	0x2500
PIC16F1947		0x2520
PIC16F1947	a0	0x2520
PIC16F610		0x2260
PIC16F610	a0	0x520
PIC16F616		0x1240
PIC16F616	a0	0x520
PIC16F627		0x7a0
PIC16F627A		0x1040
PIC16F628		0x7c0
PIC16F628A		0x1060
PIC16F630		0x10c0
PIC16F631		0x1420
PIC16F636		0x10a0
PIC16F639		0x10a0
PIC16F648A		0x1100
PIC16F676		0x10e0
PIC16F677		0x1440
PIC16F684		0x1080
PIC16F685		0x4a0
PIC16F687		0x1320
PIC16F688		0x1180
PIC16F689		0x1340
PIC16F690		0x1400
PIC16F707		0x1ac0
PIC16F707	a0	0x1AC0
PIC16F716		0x1140
PIC16F72		0xa0
PIC16F72	a0	0xa0
PIC16F72	a1	0xa1
PIC16F72	a2	0xa2
PIC16F720		0x1c00

Device:	Rev:	Device ID:
PIC16F721		0x1c20
PIC16F722		0x1880
PIC16F722	a1	0x189e
PIC16F722A		0x1b20
PIC16F723		0x1860
PIC16F723	a1	0x187e
PIC16F723A		0x1b00
PIC16F723A	a2	0x1b02
PIC16F724		0x1840
PIC16F726		0x1820
PIC16F727		0x1800
PIC16F73		0x600
PIC16F73	Rev B	0x600
PIC16F73	Rev C	0x601
PIC16F737		0xba0
PIC16F737	a0	0xba0
PIC16F74		0x620
PIC16F74	Rev B	0x620
PIC16F74	Rev C	0x621
PIC16F747		0xbe0
PIC16F747	a0	0xbe0
PIC16F76		0x640
PIC16F76	Rev B	0x640
PIC16F76	Rev C	0x641
PIC16F767		0xea0
PIC16F767	a0	0xea0
PIC16F77		0x660
PIC16F77	Rev B	0x660
PIC16F77	Rev C	0x661
PIC16F777		0xde0
PIC16F777	a0	0xde0
PIC16F777	a1	0xde1
PIC16F785		0x1200
PIC16F818		0x4c0
PIC16F818	a0	0x4c0
PIC16F818	a1	0x4c1
PIC16F818	a2	0x4c2
PIC16F818	a3	0x4c3
PIC16F818	a4	0x4c4
PIC16F819		0x4e0
PIC16F819	a0	0x4e0
PIC16F819	a1	0x4e1
PIC16F819	a2	0x4e2
PIC16F819	a3	0x4e3
PIC16F819	a4	0x4e4
PIC16F84A		0x560
PIC16F87		0x720
PIC16F87	a0	0x720
PIC16F87	a1	0x721
PIC16F87	a2	0x722
PIC16F87	a3	0x723
PIC16F87	b0	0x724
PIC16F87	b1	0x725
PIC16F870		0xd00
PIC16F870	a0	0xd00

Device:	Rev:	Device ID:
PIC16F870	a1, a2	0xd01
PIC16F870	a3	0xd02
PIC16F871		0xd20
PIC16F871	a0	0xd20
PIC16F871	a1, a2	0xd21
PIC16F871	a3	0xd22
PIC16F872		0x8e0
PIC16F872	a1	0x8e0
PIC16F872	a2	0x8e1
PIC16F873		0x960
PIC16F873	a0	0x960
PIC16F873	a1	0x961
PIC16F873	b0, b1	0x962
PIC16F873	b2, b3	0x963
PIC16F873	b4, b5, b6	0x964
PIC16F873	b7	0x965
PIC16F873	b8	0x966
PIC16F873A		0xe40
PIC16F873A	a0, a1	0xe40
PIC16F873A	b0	0xe41
PIC16F873A	b1	0xe42
PIC16F873A	b2	0xe43
PIC16F873A	b3	0xe46
PIC16F873A	b4	0xe47
PIC16F874		0x920
PIC16F874	a0	0x920
PIC16F874	a1	0x921
PIC16F874	b0, b1	0x922
PIC16F874	b2, b3	0x923
PIC16F874	b4, b5, b6	0x924
PIC16F874	b7	0x925
PIC16F874	b8	0x926
PIC16F874A		0xe60
PIC16F874A	a0, a1	0xe60
PIC16F874A	b0	0xe61
PIC16F874A	b1	0xe62
PIC16F874A	b2	0xe63
PIC16F874A	b3	0xe66
PIC16F874A	b4	0xe67
PIC16F876		0x9e0
PIC16F876	a0	0x9e0
PIC16F876	a1	0x9e1
PIC16F876	b0, b1	0x9e2
PIC16F876	b2, b3	0x9e3
PIC16F876	b4, b5, b6	0x9e4
PIC16F876	b7	0x9e5
PIC16F876	b8	0x9e6
PIC16F876A		0xe00
PIC16F876A	a0, a1	0xe00
PIC16F876A	b0	0xe01
PIC16F876A	b1	0xe02
PIC16F876A	b2	0xe03
PIC16F876A	b3	0xe06
PIC16F876A	b4	0xe07
PIC16F877		0x9a0

Device:	Rev:	Device ID:
PIC16F877	a0	0x9a0
PIC16F877	a1	0x9a1
PIC16F877	b0, b1	0x9a2
PIC16F877	b2, b3	0x9a3
PIC16F877	b4, b5, b6	0x9a4
PIC16F877	b7	0x9a5
PIC16F877	b8	0x9a6
PIC16F877A		0xe20
PIC16F877A	a0, a1	0xe20
PIC16F877A	b0	0xe21
PIC16F877A	b1	0xe22
PIC16F877A	b2	0xe23
PIC16F877A	b3	0xe26
PIC16F877A	b4	0xe27
PIC16F88		0x760
PIC16F88	a0	0x760
PIC16F88	a1	0x761
PIC16F88	a2	0x762
PIC16F88	a3	0x763
PIC16F88	b0	0x764
PIC16F88	b1	0x765
PIC16F882		0x2000
PIC16F883		0x2020
PIC16F884		0x2040
PIC16F886		0x2060
PIC16F887		0x2080
PIC16F913		0x13e0
PIC16F914		0x13c0
PIC16F916		0x13a0
PIC16F916	a1	0x13a0
PIC16F917		0x1380
PIC16F917	a1	0x1380
PIC16F946		0x1460
PIC16F946	a0	0x1460
PIC16HV610		0x22a0
PIC16HV610	a0	0x520
PIC16HV616		0x1260
PIC16HV616	a0	0x520
PIC16HV785		0x1220
PIC16LF1516		0x1780
PIC16LF1516	a0	0x16E0
PIC16LF1517		0x17a0
PIC16LF1517	a0	0x16E0
PIC16LF1518		0x17c0
PIC16LF1518	a0	0x16E0
PIC16LF1519		0x17e0
PIC16LF1519	a0	0x16E0
PIC16LF1526		0x15c0
PIC16LF1526	a0	0x15C0
PIC16LF1527		0x15e0
PIC16LF1527	a0	0x15E0
PIC16LF1782		0x2aa0
PIC16LF1782	a0	0x2AA0
PIC16LF1783		0x2ac0
PIC16LF1783	a0	0x2AC0

Device:	Rev:	Device ID:
PIC16LF1823		0x2820
PIC16LF1823	a0	0x2820
PIC16LF1824		0x2840
PIC16LF1824	a0	0x2840
PIC16LF1825		0x2860
PIC16LF1825	a0	0x2860
PIC16LF1826		0x2880
PIC16LF1826	a0	0x2880
PIC16LF1827		0x28a0
PIC16LF1827	a0	0x28A0
PIC16LF1828		0x28c0
PIC16LF1828	a0	0x28C0
PIC16LF1829		0x28e0
PIC16LF1829	a0	0x28E0
PIC16LF1847		0x14a0
PIC16LF1847	a0	0x14A0
PIC16LF1902		0x2420
PIC16LF1902	a0	0x2400
PIC16LF1903		0x2c00
PIC16LF1903	a0	0x2400
PIC16LF1904		0x2400
PIC16LF1904	a0	0x2400
PIC16LF1906		0x2400
PIC16LF1906	a0	0x2400
PIC16LF1907		0x2400
PIC16LF1907	a0	0x2400
PIC16LF1933		0x2400
PIC16LF1933	a0	0x2400
PIC16LF1934		0x2440
PIC16LF1934	a0	0x2440
PIC16LF1936		0x2460
PIC16LF1936	a0	0x2460
PIC16LF1937		0x2480
PIC16LF1937	a0	0x2480
PIC16LF1938		0x24a0
PIC16LF1938	a0	0x24A0
PIC16LF1939		0x24c0
PIC16LF1939	a0	0x23C0
PIC16LF1946		0x2580
PIC16LF1946	a0	0x2580
PIC16LF1947		0x25a0
PIC16LF1947	a0	0x25A0
PIC16LF707		0x1ae0
PIC16LF707	a0	0x1AE0
PIC16LF720		0x1c40
PIC16LF721		0x1c60
PIC16LF722		0x1980
PIC16LF722	a1	0x199e
PIC16LF722A		0x1b60
PIC16LF722A	a2	0x1b62
PIC16LF723		0x1960
PIC16LF723	a1	0x197e
PIC16LF723A		0x1b40
PIC16LF723A	a2	0x1b42
PIC16LF724		0x1940

Device:	Rev:	Device ID:
PIC16LF726		0x1920
PIC16LF727		0x1900
PIC18C242		0x320
PIC18C242	a0	0x320
PIC18C242	a1	0x321
PIC18C252		0x220
PIC18C252	a0	0x220
PIC18C252	a1	0x221
PIC18C442		0x300
PIC18C442	a0	0x300
PIC18C442	a1	0x301
PIC18C452		0x200
PIC18C452	a0	0x200
PIC18C452	a1	0x201
PIC18C601		0x120
PIC18C601	a0	0x120
PIC18C601	b0	0x121
PIC18C601	b1	0x122
PIC18C601	c0	0x123
PIC18C658		0xa0
PIC18C658	a0	0xa0
PIC18C658	rev b	0xa1
PIC18C658	c2	0xa2
PIC18C658	c3	0xa3
PIC18C801		0x100
PIC18C801	a0	0x100
PIC18C801	b0	0x101
PIC18C801	b1	0x102
PIC18C801	c0	0x103
PIC18C858		0xe0
PIC18C858	a0	0xe0
PIC18C858	rev b	0xe1
PIC18C858	c3	0xe3
PIC18CR6627		0x13c0
PIC18CR8627		0x13e0
PIC18F1220		0x7e0
PIC18F1220	rev a	0x7c0
PIC18F1220	b0	0x7c1
PIC18F1220	b1	0x7c2
PIC18F1220	b2,b3	0x7c3
PIC18F1220	b4	0x7c4
PIC18F1230		0x1e00
PIC18F1230	rev a	0x1e00
PIC18F1230	rev b0	0x1e02
PIC18F1231		0x1E80
PIC18F1231	rev a	0x1E80
PIC18F1320		0x7c0
PIC18F1320	rev a	0x7c0
PIC18F1320	b0	0x7c1
PIC18F1320	b1	0x7c2
PIC18F1320	b2,b3	0x7c3
PIC18F1320	b4	0x7c4
PIC18F1330		0x1e20
PIC18F1330	rev a	0x1e20
PIC18F1330	rev b0	0x1e22

Device:	Rev:	Device ID:
PIC18F1331		0x1EA0
PIC18F1331	rev a	0x1EA0
PIC18F13K20		0x4f40
PIC18F13K22		0x4f40
PIC18F13K50		0x4740
PIC18F14K20		0x4f20
PIC18F14K22		0x4f20
PIC18F14K50		0x4760
PIC18F2220		0x580
PIC18F2220	b2	0x583
PIC18F2220	c0	0x585
PIC18F2221		0x2160
PIC18F2320		0x500
PIC18F2320	b2	0x503
PIC18F2320	c0	0x505
PIC18F2321		0x2120
PIC18F2331		0x8e0
PIC18F2331	a0	0x8e0
PIC18F2331	a1	0x8e1
PIC18F23K20		0x20e0
PIC18F23K22		0x5740
PIC18F2410		0x1160
PIC18F242		0x480
PIC18F242	a0, a1	0x480
PIC18F242	a2	0x481
PIC18F242	b0	0x482
PIC18F242	b1	0x483
PIC18F242	b2, b3, b4	0x484
PIC18F242	b5	0x486
PIC18F242	c0	0x487
PIC18F2420		0x1140
PIC18F2423		0x1150
PIC18F2431		0x8c0
PIC18F2431	a0	0x8c0
PIC18F2439		0x480
PIC18F2450		0x2420
PIC18F2455		0x1260
PIC18F2455	a0	0x1260
PIC18F2455	a2	0x1261
PIC18F2455	a3	0x1262
PIC18F2458		0x2a60
PIC18F248		0x800
PIC18F248	rev a	0x800
PIC18F248	b0	0x801
PIC18F248	b1, b2	0x802
PIC18F248	b3	0x803
PIC18F248	b4	0x804
PIC18F248	c0	0x805
PIC18F2480		0x1ae0
PIC18F24J10		0x1d00
PIC18F24J11		0x4d80
PIC18F24J50		0x4c00
PIC18F24K20		0x20a0
PIC18F24K22		0x5640
PIC18F2510		0x1120

Device:	Rev:	Device ID:
PIC18F2515		0xce0
PIC18F2515	a0	0xce0
PIC18F2515	a1	0xce1
PIC18F2515	a2	0xce2
PIC18F2515	a3	0xce3
PIC18F2515	a4	0xce4
PIC18F252		0x400
PIC18F252	a0, a1	0x400
PIC18F252	a2	0x401
PIC18F252	b0	0x402
PIC18F252	b1	0x403
PIC18F252	b2, b3, b4	0x404
PIC18F252	b5	0x406
PIC18F252	c0	0x407
PIC18F2520		0x1100
PIC18F2520	a0	0x1100
PIC18F2523		0x1110
PIC18F2523	a0	0x1110
PIC18F2525		0xcc0
PIC18F2525	a0	0xcc0
PIC18F2525	a1	0xcc1
PIC18F2525	a2	0xcc2
PIC18F2525	a3	0xcc3
PIC18F2525	a4	0xcc4
PIC18F2539		0x400
PIC18F2550		0x1240
PIC18F2550	a0	0x1240
PIC18F2550	a2	0x1241
PIC18F2550	a3	0x1242
PIC18F2553		0x2a40
PIC18F258		0x840
PIC18F258	rev a	0x840
PIC18F258	b0	0x841
PIC18F258	b1, b2	0x842
PIC18F258	b3	0x843
PIC18F258	b4	0x844
PIC18F258	c0	0x845
PIC18F2580		0x1ac0
PIC18F2585		0xee0
PIC18F2585	a0	0xee0
PIC18F2585	a1	0xee1
PIC18F2585	a2	0xee2
PIC18F2586		0x0E60
PIC18F25J10		0x1c00
PIC18F25J11		0x4da0
PIC18F25J50		0x4c20
PIC18F25K20		0x2060
PIC18F25K22		0x5540
PIC18F25K80		0x6180
PIC18F25K80	a0	0xe80
PIC18F25K80	a1	0xe81
PIC18F25K80	a2	0xe82
PIC18F2610		0xca0
PIC18F2610	a0	0xca0
PIC18F2610	a1	0xca1

Device:	Rev:	Device ID:
PIC18F2610	a2	0xca2
PIC18F2610	a3	0xca3
PIC18F2610	a4	0xca4
PIC18F2620		0xc80
PIC18F2620	a0	0xc80
PIC18F2620	a1	0xc81
PIC18F2620	a2	0xc82
PIC18F2620	a3	0xc83
PIC18F2620	a4	0xc84
PIC18F2680		0xec0
PIC18F2680	a0	0xec0
PIC18F2680	a1	0xec1
PIC18F2680	a2	0xec2
PIC18F2682		0x2700
PIC18F2685		0x2720
PIC18F26J11		0x4dc0
PIC18F26J13		0x5920
PIC18F26J50		0x4c40
PIC18F26J53		0x5820
PIC18F26K20		0x2020
PIC18F26K20	a0	0x2000
PIC18F26K22		0x5440
PIC18F26K80		0x6120
PIC18F26K80	a0	0xe80
PIC18F26K80	a1	0xe81
PIC18F26K80	a2	0xe82
PIC18F27J13		0x5960
PIC18F27J53		0x5860
PIC18F4220		0x5a0
PIC18F4220	b2	0x5a3
PIC18F4220	b3	0x5a4
PIC18F4220	c0	0x5a5
PIC18F4221		0x2140
PIC18F4320		0x520
PIC18F4320	a0	0x520
PIC18F4320	a1	0x521
PIC18F4320	a2	0x522
PIC18F4320	b2	0x523
PIC18F4320	c0	0x525
PIC18F4321		0x2100
PIC18F4331		0x8a0
PIC18F4331	a0	0x8a0
PIC18F4331	a1	0x8a1
PIC18F43K20		0x20c0
PIC18F43K22		0x5700
PIC18F4410		0x10e0
PIC18F442		0x4a0
PIC18F442	a0, a1	0x4a0
PIC18F442	a2	0x4a1
PIC18F442	b0	0x4a2
PIC18F442	b1	0x4a3
PIC18F442	b2, b3, b4	0x4a4
PIC18F442	b5	0x4a6
PIC18F442	c0	0x4a7
PIC18F4420		0x10c0

Device:	Rev:	Device ID:
PIC18F4423		0x10d0
PIC18F4431		0x880
PIC18F4431	a0	0x880
PIC18F4431	a1	0x881
PIC18F4439		0x4a0
PIC18F4450		0x2400
PIC18F4455		0x1220
PIC18F4455	a0	0x1220
PIC18F4455	a2	0x1221
PIC18F4455	a3	0x1222
PIC18F4458		0x2a20
PIC18F448		0x820
PIC18F448	rev a	0x820
PIC18F448	b0	0x821
PIC18F448	b1, b2	0x822
PIC18F448	b3	0x823
PIC18F448	b4	0x824
PIC18F448	c0	0x825
PIC18F4480		0x1aa0
PIC18F44J10		0x1d20
PIC18F44J11		0x4de0
PIC18F44J50		0x4c60
PIC18F44K20		0x2080
PIC18F44K22		0x5600
PIC18F4510		0x10a0
PIC18F4515		0xc60
PIC18F4515	a0	0xc60
PIC18F4515	a1	0xc61
PIC18F4515	a2	0xc62
PIC18F4515	a3	0xc63
PIC18F4515	a4	0xc64
PIC18F452		0x420
PIC18F452	a0, a1	0x420
PIC18F452	a2	0x421
PIC18F452	b0	0x422
PIC18F452	b1	0x423
PIC18F452	b2, b3, b4	0x424
PIC18F452	b5	0x426
PIC18F452	c0	0x427
PIC18F4520		0x1080
PIC18F4520	a0	0x1080
PIC18F4523		0x1090
PIC18F4523	a0	0x1090
PIC18F4525		0xc40
PIC18F4525	a0	0xc40
PIC18F4525	a1	0xc41
PIC18F4525	a2	0xc42
PIC18F4525	a3	0xc43
PIC18F4525	a4	0xc44
PIC18F4539		0x420
PIC18F4550		0x1200
PIC18F4550	a1	0x1200
PIC18F4550	a2	0x1201
PIC18F4550	a3	0x1202
PIC18F4553		0x2a00

Device:	Rev:	Device ID:
PIC18F458		0x860
PIC18F458	rev a	0x860
PIC18F458	b0	0x861
PIC18F458	b1,b2	0x862
PIC18F458	b3	0x863
PIC18F458	b4	0x864
PIC18F458	c0	0x865
PIC18F4580		0x1a80
PIC18F4585		0xea0
PIC18F4585	a0	0xea0
PIC18F4585	a1	0xea1
PIC18F4585	a2	0xea2
PIC18F4586		0x0E20
PIC18F45J10		0x1c20
PIC18F45J11		0x4e00
PIC18F45J50		0x4c80
PIC18F45K20		0x2040
PIC18F45K22		0x5500
PIC18F45K80		0x6160
PIC18F45K80	a0	0xe80
PIC18F45K80	a1	0xe81
PIC18F45K80	a2	0xe82
PIC18F4610		0xc20
PIC18F4610	a0	0xc20
PIC18F4610	a1	0xc21
PIC18F4610	a2	0xc22
PIC18F4610	a3	0xc23
PIC18F4610	a4	0xc24
PIC18F4620		0xc00
PIC18F4620	a0	0xc00
PIC18F4620	a1	0xc01
PIC18F4620	a2	0xc02
PIC18F4620	a3	0xc03
PIC18F4620	a4	0xc04
PIC18F4680		0xe80
PIC18F4680	a0	0xe80
PIC18F4680	a1	0xe81
PIC18F4680	a2	0xe82
PIC18F4682		0x2740
PIC18F4685		0x2760
PIC18F46J11		0x4e20
PIC18F46J13		0x59a0
PIC18F46J50		0x4ca0
PIC18F46J53		0x58a0
PIC18F46K20		0x2000
PIC18F46K20	a0	0x2000
PIC18F46K22		0x5400
PIC18F46K80		0x6100
PIC18F46K80	a0	0xe80
PIC18F46K80	a1	0xe81
PIC18F46K80	a2	0xe82
PIC18F47J13		0x59e0
PIC18F47J53		0x58e0
PIC18F6310		0xbe0
PIC18F6313		0x1a40

Device:	Rev:	Device ID:
PIC18F6390		0xba0
PIC18F6393		0x1a00
PIC18F63J11		0x3900
PIC18F63J90		0x3800
PIC18F6410		0x6e0
PIC18F6410	a0	0x6e0
PIC18F6413		0xe40
PIC18F6413	a0	0x6e0
PIC18F6490		0x6a0
PIC18F6490	a0	0x6a0
PIC18F6493		0xe00
PIC18F6493	a0	0x6a0
PIC18F64J11		0x3920
PIC18F64J90		0x3820
PIC18F6520		0xb20
PIC18F6520	a0	0xb20
PIC18F6520	a1	0xb21
PIC18F6520	a1, low power	0xb31
PIC18F6525		0xae0
PIC18F6525	a0	0xae0
PIC18F6525	a1	0xae1
PIC18F6527		0x1340
PIC18F6527	a0	0x1340
PIC18F6585		0xa60
PIC18F6585	a0	0xa60
PIC18F6585	a1	0xa61
PIC18F65J10		0x1520
PIC18F65J11		0x3960
PIC18F65J15		0x1540
PIC18F65J50		0x4100
PIC18F65J90		0x3860
PIC18F65K22		0x5300
PIC18F65K80		0x6140
PIC18F65K80	a0	0xe80
PIC18F65K80	a1	0xe81
PIC18F65K80	a2	0xe82
PIC18F65K90		0x5240
PIC18F6620		0x660
PIC18F6620	a1	0x661
PIC18F6620	a2	0x662
PIC18F6620	a3	0x663
PIC18F6620	a4	0x664
PIC18F6621		0xaa0
PIC18F6621	a0	0xaa0
PIC18F6621	a1	0xaa1
PIC18F6622		0x1380
PIC18F6622	a0	0x1380
PIC18F6627		0x13c0
PIC18F6628		0x49c0
PIC18F6680		0xa20
PIC18F6680	a0	0xa20
PIC18F6680	a1	0xa21
PIC18F66J10		0x1560
PIC18F66J11		0x4440
PIC18F66J15		0x1580

Device:	Rev:	Device ID:
PIC18F66J16		0x4460
PIC18F66J50		0x4140
PIC18F66J55		0x4160
PIC18F66J60		0x1800
PIC18F66J65		0x1f00
PIC18F66J90		0x5000
PIC18F66J93		0x5040
PIC18F66K22		0x52c0
PIC18F66K27		0x51a0
PIC18F66K80		0x60e0
PIC18F66K80	a0	0xe80
PIC18F66K80	a1	0xe81
PIC18F66K80	a2	0xe82
PIC18F66K90		0x5200
PIC18F66K95		0x5120
PIC18F6720		0x620
PIC18F6720	a1	0x621
PIC18F6720	a2	0x622
PIC18F6720	a3	0x623
PIC18F6720	a4	0x624
PIC18F6722		0x1400
PIC18F6723		0x4a00
PIC18F67J10		0x15a0
PIC18F67J11		0x4480
PIC18F67J50		0x4180
PIC18F67J60		0x1f20
PIC18F67J90		0x5020
PIC18F67J93		0x5060
PIC18F67K22		0x5180
PIC18F67K90		0x5100
PIC18F8310		0xbc0
PIC18F8313		0x1a60
PIC18F8390		0xb80
PIC18F8393		0x1a20
PIC18F83J11		0x3980
PIC18F83J90		0x3880
PIC18F8410		0x6c0
PIC18F8410	a0	0x6c0
PIC18F8413		0xe60
PIC18F8413	a0	0x6c0
PIC18F8490		0x680
PIC18F8490	a0	0x680
PIC18F8493		0xe20
PIC18F8493	a0	0x680
PIC18F84J11		0x39a0
PIC18F84J90		0x38a0
PIC18F8520		0xb00
PIC18F8520	a0	0xb00
PIC18F8520	a1	0xb01
PIC18F8520	a1, low power	0xb11
PIC18F8525		0xac0
PIC18F8525	a0	0xac0
PIC18F8525	a1	0xac1
PIC18F8527		0x1360
PIC18F8527	a0	0x1360

Device:	Rev:	Device ID:
PIC18F8585		0xa40
PIC18F8585	a0	0xa40
PIC18F8585	a1	0xa41
PIC18F85J10		0x15e0
PIC18F85J11		0x39e0
PIC18F85J15		0x1700
PIC18F85J50		0x41a0
PIC18F85J90		0x38e0
PIC18F85K22		0x5360
PIC18F85K90		0x52a0
PIC18F8620		0x640
PIC18F8620	a1	0x641
PIC18F8620	a2	0x642
PIC18F8620	a3	0x643
PIC18F8620	a4	0x644
PIC18F8621		0xa80
PIC18F8621	a0	0xa80
PIC18F8621	a1	0xa81
PIC18F8622		0x13a0
PIC18F8622	a0	0x13a0
PIC18F8627		0x13e0
PIC18F8628		0x49e0
PIC18F8680		0xa00
PIC18F8680	a0	0xa00
PIC18F8680	a1	0xa01
PIC18F86J10		0x1720
PIC18F86J11		0x44e0
PIC18F86J15		0x1740
PIC18F86J16		0x4500
PIC18F86J50		0x41e0
PIC18F86J55		0x4200
PIC18F86J60		0x1820
PIC18F86J65		0x1f40
PIC18F86J72		0x5040
PIC18F86J90		0x5080
PIC18F86J93		0x50c0
PIC18F86K22		0x5320
PIC18F86K27		0x51e0
PIC18F86K90		0x5260
PIC18F86K95		0x5160
PIC18F8720		0x600
PIC18F8720	a1	0x601
PIC18F8720	a2	0x602
PIC18F8720	a3	0x603
PIC18F8720	a4	0x604
PIC18F8722		0x1420
PIC18F8723		0x4a20
PIC18F87J10		0x1760
PIC18F87J11		0x4520
PIC18F87J50		0x4220
PIC18F87J60		0x1f60
PIC18F87J72		0x5060
PIC18F87J90		0x50a0
PIC18F87J93		0x50e0
PIC18F87K22		0x51c0

Device:	Rev:	Device ID:
PIC18F87K90		0x5140
PIC18F96J60		0x1840
PIC18F96J65		0x1f80
PIC18F96J72		0x50c0
PIC18F97J60		0x1fa0
PIC18F97J72		0x50e0
PIC18LF13K22		0x4f80
PIC18LF13K50		0x4700
PIC18LF14K22		0x4f60
PIC18LF14K50		0x4720
PIC18LF23K10		0x20e0
PIC18LF23K22		0x5760
PIC18LF24J10		0x1d40
PIC18LF24J11		0x4e40
PIC18LF24J50		0x4cc0
PIC18LF24K10		0x20a0
PIC18LF24K22		0x5660
PIC18LF25J10		0x1c40
PIC18LF25J11		0x4e60
PIC18LF25J50		0x4ce0
PIC18LF25K10		0x2060
PIC18LF25K22		0x5560
PIC18LF25K80		0x6260
PIC18LF25K80	a0	0xe80
PIC18LF25K80	a1	0xe81
PIC18LF25K80	a2	0xe82
PIC18LF26J11		0x4e80
PIC18LF26J13		0x5b20
PIC18LF26J50		0x4d00
PIC18LF26J53		0x5a20
PIC18LF26K10		0x2020
PIC18LF26K10	a0	0x2000
PIC18LF26K22		0x5460
PIC18LF26K80		0x6200
PIC18LF26K80	a0	0xe80
PIC18LF26K80	a1	0xe81
PIC18LF26K80	a2	0xe82
PIC18LF27J13		0x5b60
PIC18LF27J53		0x5a60
PIC18LF43K10		0x20c0
PIC18LF43K22		0x5720
PIC18LF44J10		0x1d60
PIC18LF44J11		0x4ea0
PIC18LF44J50		0x4d20
PIC18LF44K10		0x2080
PIC18LF44K22		0x5620
PIC18LF45J10		0x1c60
PIC18LF45J11		0x4ec0
PIC18LF45J50		0x4d40
PIC18LF45K10		0x2040
PIC18LF45K22		0x5520
PIC18LF45K80		0x6240
PIC18LF45K80	a0	0xe80
PIC18LF45K80	a1	0xe81
PIC18LF45K80	a2	0xe82

Device:	Rev:	Device ID:
PIC18LF46J11		0x4ee0
PIC18LF46J13		0x5ba0
PIC18LF46J50		0x4d60
PIC18LF46J53		0x5aa0
PIC18LF46K10		0x2000
PIC18LF46K10	a0	0x2000
PIC18LF46K22		0x5420
PIC18LF46K80		0x61e0
PIC18LF46K80	a0	0xe80
PIC18LF46K80	a1	0xe81
PIC18LF46K80	a2	0xe82
PIC18LF47J13		0x5be0
PIC18LF47J53		0x5ae0
PIC18LF65K80		0x6220
PIC18LF65K80	a0	0xe80
PIC18LF65K80	a1	0xe81
PIC18LF65K80	a2	0xe82
PIC18LF66K80		0x61c0
PIC18LF66K80	a0	0xe80
PIC18LF66K80	a1	0xe81
PIC18LF66K80	a2	0xe82
PIC24EP256GU810		0x18264000
PIC24EP256GU814		0x18274000
PIC24EP512GU810		0x18364000
PIC24EP512GU814		0x18374000
PIC24F04KA200		0xd020000
PIC24F04KA201		0xd000000
PIC24F08KA101		0xd080000
PIC24F08KA102		0xd0a0000
PIC24F16KA101		0xd010000
PIC24F16KA102		0xd030000
PIC24F16KA301		0x45080000
PIC24F16KA302		0x45020000
PIC24F16KA304		0x45060000
PIC24F16KL402		0x4b1d0000
PIC24F32KA101		0xb090000
PIC24F32KA102		0xb0b0000
PIC24F32KA301		0x45180000
PIC24F32KA302		0x45120000
PIC24F32KA304		0x45160000
PIC24FJ128DA106		0x41090000
PIC24FJ128DA110		0x410b0000
PIC24FJ128DA206		0x41080000
PIC24FJ128DA210		0x410a0000
PIC24FJ128GA006		0x4070000
PIC24FJ128GA008		0x40a0000
PIC24FJ128GA010		0x40d0000
PIC24FJ128GA010PS		0x100b0000
PIC24FJ128GA106		0x10080000
PIC24FJ128GA108		0x100a0000
PIC24FJ128GA110		0x100e0000
PIC24FJ128GA306		0x46c20000
PIC24FJ128GA308		0x46c60000
PIC24FJ128GA310		0x46ca0000
PIC24FJ128GA315		0x46ca0000

Device:	Rev:	Device ID:
PIC24FJ128GB106		0x10090000
PIC24FJ128GB108		0x100b0000
PIC24FJ128GB110		0x100f0000
PIC24FJ128GB206		0x41000000
PIC24FJ128GB210		0x41020000
PIC24FJ16GA002		0x44400000
PIC24FJ16GA004		0x44c00000
PIC24FJ16MC101		0x20630000
PIC24FJ16MC102		0x20730000
PIC24FJ192GA106		0x10100000
PIC24FJ192GA108		0x10120000
PIC24FJ192GA110		0x10160000
PIC24FJ192GB106		0x10110000
PIC24FJ192GB108		0x10130000
PIC24FJ192GB110		0x10170000
PIC24FJ256DA106		0x410d0000
PIC24FJ256DA110		0x410f0000
PIC24FJ256DA206		0x410c0000
PIC24FJ256DA210		0x410e0000
PIC24FJ256GA106		0x10180000
PIC24FJ256GA108		0x101a0000
PIC24FJ256GA110		0x101e0000
PIC24FJ256GB106		0x10190000
PIC24FJ256GB108		0x101b0000
PIC24FJ256GB110		0x101f0000
PIC24FJ256GB206		0x41040000
PIC24FJ256GB210		0x41060000
PIC24FJ32GA002		0x44500000
PIC24FJ32GA004		0x44d00000
PIC24FJ32GA102		0x42020000
PIC24FJ32GA104		0x420a0000
PIC24FJ32GB002		0x42030000
PIC24FJ32GB004		0x420b0000
PIC24FJ48GA002		0x44600000
PIC24FJ48GA004		0x44e00000
PIC24FJ64GA002		0x44700000
PIC24FJ64GA004		0x44f00000
PIC24FJ64GA006		0x40500000
PIC24FJ64GA008		0x40800000
PIC24FJ64GA010		0x40b00000
PIC24FJ64GA102		0x42060000
PIC24FJ64GA104		0x420e0000
PIC24FJ64GA106		0x10000000
PIC24FJ64GA108		0x10020000
PIC24FJ64GA110		0x10060000
PIC24FJ64GA306		0x46c00000
PIC24FJ64GA308		0x46c40000
PIC24FJ64GA310		0x46c80000
PIC24FJ64GB002		0x42070000
PIC24FJ64GB004		0x420f0000
PIC24FJ64GB106		0x10010000
PIC24FJ64GB108		0x10030000
PIC24FJ64GB110		0x10070000
PIC24FJ96GA006		0x40600000
PIC24FJ96GA008		0x40900000

Device:	Rev:	Device ID:
PIC24FJ96GA010		0x40c0000
PIC24FV16KA301		0x45090000
PIC24FV16KA302		0x45030000
PIC24FV16KA304		0x45070000
PIC24FV32KA301		0x45190000
PIC24FV32KA302		0x45130000
PIC24FV32KA304		0x45170000
PIC24HJ128GP202		0x6650000
PIC24HJ128GP204		0x6670000
PIC24HJ128GP206		0x5d3000
PIC24HJ128GP206A		0x5d3000
PIC24HJ128GP210		0x5f3000
PIC24HJ128GP210A		0x5f3000
PIC24HJ128GP302		0x650000
PIC24HJ128GP304		0x660000
PIC24HJ128GP306		0x653000
PIC24HJ128GP306A		0x653000
PIC24HJ128GP310		0x673000
PIC24HJ128GP310A		0x673000
PIC24HJ128GP502		0x67d0000
PIC24HJ128GP504		0x67f0000
PIC24HJ128GP506		0x613000
PIC24HJ128GP506A		0x613000
PIC24HJ128GP510		0x633000
PIC24HJ128GP510A		0x633000
PIC24HJ128GP802		0x6d0000
PIC24HJ128GP804		0x006e0000
PIC24HJ12GP201		0x80a0000
PIC24HJ12GP202		0x80b0000
PIC24HJ12MC201		0x8080000
PIC24HJ12MC202		0x8090000
PIC24HJ16GP302		0x00000F15
PIC24HJ16GP304		0xf170000
PIC24HJ16MC302		0xf110000
PIC24HJ16MC304		0xf120000
PIC24HJ256GP206		0x713000
PIC24HJ256GP206A		0x7710000
PIC24HJ256GP210		0x733000
PIC24HJ256GP210A		0x7730000
PIC24HJ256GP610		0x7b3000
PIC24HJ256GP610A		0x77b0000
PIC24HJ32GP202		0xf1d0000
PIC24HJ32GP204		0xf1f0000
PIC24HJ32GP302		0x6450000
PIC24HJ32GP304		0x6470000
PIC24HJ32MC202		0xf190000
PIC24HJ32MC204		0xf1b0000
PIC24HJ64GP202		0x6550000
PIC24HJ64GP204		0x6570000
PIC24HJ64GP206		0x413000
PIC24HJ64GP206A		0x413000
PIC24HJ64GP210		0x473000
PIC24HJ64GP210A		0x473000
PIC24HJ64GP502		0x6750000
PIC24HJ64GP504		0x6770000

Device:	Rev:	Device ID:
PIC24HJ64GP506		0x493000
PIC24HJ64GP506A		0x493000
PIC24HJ64GP510		0x4b3000
PIC24HJ64GP510A		0x4b3000
PIC24LF16KA301		0x4508000
PIC24LF16KA302		0x4502000
PIC24LF16KA304		0x4506000
PIC24LF32KA301		0x4518000
PIC24LF32KA302		0x4512000
PIC24LF32KA304		0x4516000
PIC32MX300F032H		0x900053
PIC32MX310F032H		0x900053
PIC32MX320F032H		0x902053
PIC32MX320F064H		0x906053
PIC32MX320F128H		0x90a053
PIC32MX320F128L		0x92a053
PIC32MX340F128H		0x90d053
PIC32MX340F128L		0x92d053
PIC32MX340F256H		0x912053
PIC32MX340F512H		0x916053
PIC32MX360F256L		0x934053
PIC32MX360F512L		0x938053
PIC32MX360F512L_A0		0x38053
PIC32MX420F032H		0x942053
PIC32MX440F128H		0x4d053
PIC32MX440F128L		0x96d053
PIC32MX440F256H		0x952053
PIC32MX440F512H		0x956053
PIC32MX460F256L		0x974053
PIC32MX460F512L		0x978053
PIC32MX460F512L_A0		0x78053
PIC32MX534F064H		0x4400053
PIC32MX534F064L		0x440c053
PIC32MX564F064H		0x4401053
PIC32MX564F064L		0x440d053
PIC32MX564F128H		0x4403053
PIC32MX564F128L		0x440f053
PIC32MX565F256H		0x4309053
PIC32MX575F256H		0x4317053
PIC32MX575F256L		0x4333053
PIC32MX575F512H		0x4309053
PIC32MX575F512L		0x430f053
PIC32MX586F512L		0x4309053
PIC32MX664F064H		0x4405053
PIC32MX664F064L		0x4411053
PIC32MX664F128H		0x4407053
PIC32MX664F128L		0x4413053
PIC32MX675F256H		0x430b053
PIC32MX675F256L		0x4305053
PIC32MX675F512H		0x430c053
PIC32MX675F512L		0x4311053
PIC32MX695F512H		0x4325053
PIC32MX695F512L		0x4341053
PIC32MX764F128H		0x440b053
PIC32MX764F128L		0x4417053

Device:	Rev:	Device ID:
PIC32MX775F256H		0x4303053
PIC32MX775F256L		0x4312053
PIC32MX775F512H		0x430d053
PIC32MX775F512L		0x4306053
PIC32MX795F512H		0x430e053
PIC32MX795F512L		0x4307053
PIC32MXPocono		0x4309053
PICMCV18E		0x1140
PICMCV20USB		0x4700
PICRF675AF		0xfc0
PICRF675AH		0xfc0
PICRF675AK		0xfc0
PICRF675F		0xfc0
PICRF675H		0xfc0
PICRF675K		0xfc0
PS200		0x1220
PS500		0x700
PS810		0x240

